


OVEN PARTS
For Models: KEBU208SSS02
(Stainless)


Illus. No.		DESCRIPTION	Illus. No.		DESCRIPTION	IIIu: No		DESCRIPTION
110.	110.	DEGCKII HON	110.	110.	DEGCKII TICIY	-140	. 110.	DEGORII HON
1		Literature Parts	16	4452158	Tube, Vent	38	W10150077	Enclosure
	W10140563	Installation	17	4449040		39		Gasket, Enclosure
		Instructions	18	3400893	Screw	40		Valve, Solenoid
	W10162200		19	4451478	Support, Insulation	41	W10076760	Sensor, Conductivity
		Tech Sheet	20	W10169348	Bracket,			Slip Fit
	8304551				Thermostat	44	14/40054500	Tubing
	8304552		21		Mounting Rail, Side			Lower, Clear
	W10138788	Easy Set Guide		8303677BL	9	45		Upper, Yellow
	0700704	Safer Cooking Tips		8303678BL		45 46	9758598	Clamp, Crimp (6)
	9762761		22		Latch, Mortorized	40	9730390	Assembly (2)
	W10065852	French	23	4449743		47	W10194453	
2	W40452000	Dracket Dage	24	4448444	Mounting Grommet,	41	W10134433	Pressure (2)
2 3	W 10153090	Bracket, Base	0.5	4455044	Rail (6)	48	W10076930	
3	4455606	Hinge Receiver	25		Side, Chassis	70	W 10070330	(includes clamp)
	4455605		26	W10153104	Back, Chassis	49	W10142627	
4		Bumper, Door (2)	27		Liner, Oven	50		Center, Vent
5		Exhaust, Vent Slope	28	8304452	(Not serviceable) Thermal Fuse	51	4450038	
6		Divider, Vent	20 29	W10131825		52		Basin, Bottom Vent
7		Top Chassis	30	4449748		53		Stem, Tube to
8	4449809		31		Base, Chassis			Clear Hose
9	3196176		32		Retainer, Gasket			
10		Lens, Light	33		Cover, Back		FOLLOW	ING PARTS
11		Oven Light,	34		Trim, Bottom Vent			USTRATED
		Assembly	35		Orifice, Boiler			
12	4452164	Bulb, Light			Slip Fit			
13	3400832	Screw	36	W10153098	Cover, Boiler	INS	SULATION	
14		Frame, Front			Orifice			
15	8304493	Gasket, Door	37	4449154	Screw		8303965	Insulation, Wrap
								Insulation, Back

CONTROL PANEL PARTS




IIIUS	. Part	
No.	No.	DESCRIPTION
1	W10216219	Panel, Control
2	8303691	Support Appliance
		Manager
4	W10016020	Control Panel,
		Glass Touch
5	W10143290	User Interface
6	8303719	Backer, Control
7	8303887	Bracket, Enclosure
8	4449154	Screw
9	3400832	Screw
10	W10160958	Appliance Manager
11	8304441	Resistor, Drop
12	W10134765	Vapor, Stop
13	3400805	Screw

OVEN DOOR PARTS




IIIus No.	. Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus No.		DESCRIPTION
1	W10174285 3196183 8304581BL 8304377 8304378 8303746	Vent, Door Top Bracket, Door Right Left Door, Top Bracket Glass, Inner	9 10 11	8304523 8304360BL	Bracket, Handle Door Glass, Assembly With Badge	13 15 16 17	8303774SS 8304603SS	Bumper, Glass Cover,Hinge Right Left

INTERNAL OVEN PARTS



TOP VENTING PARTS



Illus. No.	Part No.	DESCRIPTION
1	8304219	Cover, Top
2	8304643	Duct, Air Outlet
2 3	4449809	Screw
4	8303972	Blower
5	9760588	Transformer,
		Lights
6	8285593	Connector, Cover
7	9762885	Transformer,
		Control
9	4449868	Block, Terminal
10	3400080	Screw
11	8303684	Vent, Control
		Panel
12		Side, Control Top
	8303518	Right
	8304255	
13	8303520	Back, Control
14	4450118	,

OPTIONAL PARTS

For Models: KEBU208SSS02 (Stainless)

Illus. Part

No. No. DESCRIPTION

PAINT, TOUCH-UP (1/2oz.)

72017 White 261869 Cord Brown 72032 Black

PAINT, SPRAY

350930 White 261900 Citrine White 830864 Black

ADHESIVE

591014 Adhesive Loctite (1/3 oz.) 482338 Sealer, Silastic (3 oz.)

WIRING HARNESS PARTS

W10143473 Harness, Latch W10157924 Harness, Main 8304372 Communication, Harness 8304612 Conduit, Double 4450800 Screw, Ground

Miscellaneous

4448950 Screw, Install (4) 98997 Clip 7103P027-60 Nut W10111330 Filter, Cartridge W10051680 Reducer, Stem W10049700 Filter Assembly W10076960 Elbow, Plug In